



**4100010 CAT 810 150A 1P DC CONTACTOR**

ITE	PART No.	DESCRIPTION	QTY
1	4107310	CONTACT TIP 810/812	2
2	4107305	ARC SHIELD 810/812	1
3	4105321	CONTACT CARRIER ASSY 810/812	1
4	4105130	COIL ASSY CAT802/810 108 16T	1
5	4107327	BEARING BLOCK 810 812	2
6	4103132	AUXILIARY CONTACT ASSY F/C DC	1
7	4107332	DRIVE BLOCK DC CONTACTORS	1
8	4107333	DRIVE ROD 810	1
9	4107302	ARC HORN 810	1
10	4105320	FLEX LEAD ASSY 810 812	1
11	4107324	CONTACT SPRING 810 812	1
12	4107331	ADJUSTING BLOCK DC CONTACTORS	1
13	4105328	ARMATURE ASSY 150A CAT 810	1
14	4105329	MAGNET ASSY 150A CAT 810	1
15	4107314	FIXED CONTACT POST 810/812	1
16	4105317	BLOWOUT COIL ASSY 810/812	1

**4100021 CAT 821 600A DC 1P.SHUNT**

	PART No.	DESCRIPTION	QTY
1	4107715	CONTACT TIP 821 823 600A	2
2	4107717	ARC SHIELD ASSY 600 & 900 AMP	1
3	4105714	CONTACT CARRIER ASSY 821 823	1
4	4105702	COIL ASSY. CAT 818/821&825	1
5	4107708	BEARING BLOCK 818 821 823 825	2
6	4103132	AUXILIARY CONTACT ASSY F/C DC	1
7	4107719	DRIVE BLOCK 821 823 825	1
8	4107718	DRIVE ROD 821 823 825	1
9	4107701	ARC HORN 821 825	1
10	4105703	FLEX ASSY. 600A DC 823	1
11	4107707	CONTACT SPRING 821 825	1
12	4107331	ADJUSTING BLOCK DC CONTACTORS	1
13	4105712	ARM ASSY 6-900A 821/825	1
14	4105713	MAG ASSY 6-900A 821/825	1
15	4107766	FIXED CONTACT POST 821 823	1
16	4105768	BLOW OUT COIL ASSY. 821 823	1

**4100017 CAT 817 300A DC 1POLE**

	PART No.	DESCRIPTION	QTY
1	4107519	CONTACT TIP 817/819	2
2	4107508	ARC SHIELD ASSY 817/819	1
3	4105514	CONTACT CARRIER ASSY 300A	1
4	4105502	COIL ASSY. (CAT 817)	1
5	4107515	BEARING BLOCK 817	2
6	4103132	AUXILIARY CONTACT ASSY F/C DC	1
7	4107332	DRIVE BLOCK DC CONTACTORS	1
8	4107520	DRIVE ROD 817	1
9	4107504	ARC HORN 817	1
10	4105516	FLEX. LEAD ASSY 300A 817	1
11	4107513	MAIN CONT SPRING 817/819	1
12	4107331	ADJUSTING BLOCK DC CONTACTORS	1
13	4105517	ARM ASSY 300A DC 817	1
14	4105518	MAG ASSY 300A DC 817	1
15	4107554	FIXED CONTACT POST 817 300A	1
16	4105557	B/O COIL ASSY. 300A	1

**4100025 CAT 825 900A DC 1P.SHUNT**

	PART No.	DESCRIPTION	QTY
1	4107903	COPPER CONTACT TIP 825/827	2
2	4107717	ARC SHIELD ASSY 600 & 900 AMP	1
3	4105714	CONTACT CARRIER ASSY 821 823	1
4	4105702	COIL ASSY. CAT 818/821&825	1
5	4107708	BEARING BLOCK 818 821 823 825	2
6	4103132	AUXILIARY CONTACT ASSY F/C DC	1
7	4107719	DRIVE BLOCK 821 823 825	1
8	4107718	DRIVE ROD 821 823 825	1
9	4107701	ARC HORN 821 825	1
10	4105902	FLEX LEAD ASSY 825 827	1
11	4107707	CONTACT SPRING 821 825	1
12	4107331	ADJUSTING BLOCK DC CONTACTORS	1
13	4105712	ARM ASSY 6-900A 821/825	1
14	4105713	MAG ASSY 6-900A 821/825	1
15	4107901	POST FIXED CONTACT 825/827	1
16	4105906	BLOW OUT COIL ASSY 825 827	1

THIRD ANGLE PROJECTION	DRAWN	GRW	25/08/08
<p>ALL DIMENSIONS IN MILLIMETERS (UNO)</p>	CHECKED		
	APPROVED		
	MATERIAL		
	FINISH		
SCALE	1:2		
JOB FILE			

DC CONTACTORS - SHUNT  
SPARE PARTS LIST

