



**4100012 CAT 812 150A DC 1P.S/C**

PART No.	DESCRIPTION	QTY
1	4107310 CONTACT TIP 810/812	1
2	4107305 ARC SHIELD 810/812	1
3	4105321 CONTACT CARRIER ASSY 810/812	1
4	4105414 COIL ASSY. (CAT 812)	1
5	4107327 BEARING BLOCK 810 812	2
6	4103132 AUXILIARY CONTACT ASSY F/C DC	1
7	4107332 DRIVE BLOCK DC CONTACTORS	1
8	4107411 DRIVE ROD 812	1
9	4107405 ARC HORN 812	1
10	4105320 FLEX LEAD ASSY 810 812	1
11	4107324 CONTACT SPRING 810 812	1
12	4107331 ADJUSTING BLOCK DC CONTACTORS	1
13	4105406 ARM ASSY 150A S/C 812	1
14	4105408 MAG ASSY 150A S/C 812	1
15	4105317 BLOWOUT COIL ASSY 810/812	1
16	4107314 FIXED CONTACT POST 810/812	1
17	4107401 OPERATING SPRING 812	2

**4100019 CAT 819 300A DC 1P.SHUNT**

PART No.	DESCRIPTION	QTY
1	4107519 CONTACT TIP 817/819	2
2	4107508 ARC SHIELD ASSY 817/819	1
3	4105514 CONTACT CARRIER ASSY 300A	1
4	4105606 COIL ASSY. CAT 819	1
5	4107515 BEARING BLOCK 817	2
6	4103132 AUXILIARY CONTACT ASSY F/C DC	1
7	4107332 DRIVE BLOCK DC CONTACTORS	1
8	4107611 DRIVE ROD 819	1
9	4107613 ARC HORN FOR CAT 819	1
10	4105516 FLEX. LEAD ASSY 300A 817	1
11	4107513 MAIN CONT SPRING 817/819	1
12	4107331 ADJUSTING BLOCK DC CONTACTORS	1
13	4105609 ARM ASSY 300A S/C 819	1
14	4105605 MAG ASSY 300A S.C 819	1
15	4105557 BLOWOUT COIL ASSY 300A	1
16	4107554 FIXED CONTACT POST 817 300A	1
17	4107607 OPERATING SPRING 819	2

**4100023 CAT 823 600A DC S/C**

PART No.	DESCRIPTION	QTY
1	4107715 CONTACT TIP 821 823 600A	2
2	4107717 ARC SHIELD ASSY 600 & 900 AMP	1
3	4105714 CONTACT CARRIER ASSY 821 823	1
4	4105812 COIL ASSY CAT 823 827	1
5	4107708 BEARING BLOCK 818 821 823 825	2
6	4103132 AUXILIARY CONTACT ASSY F/C DC	1
7	4107719 DRIVE BLOCK 821 823 825	1
8	4107718 DRIVE ROD 821 823 825	1
9	4107808 ARC HORN CAT 823/827	1
10	4105703 FLEX ASSY. 600A DC 823	1
11	4107802 CONTACT SPRING 823/827	1
12	4107331 ADJUSTING BLOCK DC CONTACTORS	1
13	4105808 ARM ASSY 600A S/C 823	1
14	4105801 MAGNET ASSY 6/900A S/C	1
15	4105768 BLOW OUT COIL ASSY. 821 823	1
16	4107766 FIXED CONTACT POST 821 823	1
17	4107803 ARMATURE SPRING CAT 823/827	2

**4100027 CAT 827 900 AMP SPRING CLOSED**

PART No.	DESCRIPTION	QTY
1	4107903 COPPER CONTACT TIP 825/827	2
2	4107717 ARC SHIELD ASSY 600 & 900 AMP	1
3	4105714 CONTACT CARRIER ASSY 821 823	1
4	4105812 COIL ASSY CAT 823 827	1
5	4107708 BEARING BLOCK 818 821 823 825	2
6	4103132 AUXILIARY CONTACT ASSY F/C DC	1
7	4107719 DRIVE BLOCK 821 823 825	1
8	4107718 DRIVE ROD 821 823 825	1
9	4107808 ARC HORN CAT 823/827	1
10	4105902 FLEX LEAD ASSY 825 827	1
11	4107802 CONTACT SPRING 823/827	1
12	4107331 ADJUSTING BLOCK DC CONTACTORS	1
13	4105808 ARM ASSY 600A S/C 823	1
14	4105801 MAGNET ASSY 6/900A S/C	1
15	4105906 BLOW OUT COIL ASSY 825 827	1
16	4107901 POST FIXED CONTACT 825/827	1
17	4107803 ARMATURE SPRING CAT 823/827	2

THIRD ANGLE PROJECTION	DRAWN	GRW	25/08/08
	CHECKED		
	APPROVED		
	MATERIAL		
	FINISH		
SCALE 1:2	JOB/TENDER		

DC CONTACTORS - SPRING CLOSED  
SPARE PARTS LIST

